



## 680.300 SOUSVIDE COOKER - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
1	ZCE160-1001	SHELL	1
2	ZCE160-1002	ENTER ASS'Y	1
3	ZCE160-1003	WATERPROOF O-RING F	1
4	ZCE160-1004	O-RING H	2
5	ZCE160-1005	JOINT B	1
6	ZCE160-1006	PANEL LOWER CASE	1
7	ZCE160-1007	CONTROL PCB	1
8	ZCE160-1008	PANEL UPPER CASE	1
9	ZCE160-1009	PANEL	1
10	ZCE160-10010	ELBOW C ASS'Y	1
11	ZCE160-10011	HEATER ASS'Y	1
12	ZCE160-10012	BOTTOM PLATE	1
13	ZCE160-10013	FOOT	4
14	ZCE160-10014	POWER PCB	1
15	ZCE160-10015	WATER PUMP	1
16	ZCE160-10016	DRAIN ASS'Y	1
17	ZCE160-10017	BODY HANDLE	1
18	ZCE160-10018	DETECTOR ASS'Y	1
19	ZCE160-10019	DETECTOR LIN ASS'Y	1

## 680.300 SOUSVIDE COOKER - SPARE PART LIST

NO	CODE	DESCRIPTION	Q'TY
20	ZCE160-10020	POWER CORD	1
21	ZCE160-10021	LINE BASE	1
22	ZCE160-10022	INPUT ASS'Y	1
23	ZCE160-10023	WATERPROOF O-RING B	1
24	ZCE160-10024	WATERPROOF O-RING A	1
25	ZCE160-10025	JOINT A	1
26	ZCE160-10026	HANG	2
27	ZCE160-10027	BOWL ASS'Y	1
28	ZCE160-10028	RISE BRACKET	1
29	ZCE160-10029	FOOD BRACKET	1
30	ZCE160-10030	COVER ASS'Y	1
31	ZCE160-10031	PUMP MOUNT	1
32	ZCE160-10032	WATER PUMP	1
33	ZCE160-10033	PIPE ASS'Y	1
34	ZCE160-10034	PIPE-1.04M	1